

				Kuenzom Automobiles	Lungten Automobiles
Sl. No	Discription	Unit	Country of origin	Rate	Rate
1	Battery terminal end	Each	THAILAND	50	180
2	A/C filter	per piece	THAILAND	50	2750
3	Alternator Assy	Each	THAILAND	50	35000
4	Alternator carbon bush	Each	THAILAND	50	2800
5	Alternator cut out	Each	THAILAND	50	2800
6	Anabond paste (Big)	Each	THAILAND	0	350
7	Anabond paste (Small)	Each	THAILAND	0	120
8	Back bumper	Each	THAILAND	0	17800
9	Back light Assy (Left)	Each	THAILAND	0	9800
10	Back light Assy (Right)	Each	THAILAND	0	9800
11	Battery cable +ive	Each	THAILAND	0	1100
12	Battery cable -ive	Each	THAILAND	0	1100
13	Bendix pinion	Each	THAILAND	0	6500
14	Black tape	per piece	THAILAND	0	45
15	Brake light switch	Each	THAILAND	0	450
16	Bulb 1141	Each	THAILAND	0	45
17	Bulb 67	Each	THAILAND	0	45
18	bush stabilzer	per piece	THAILAND	0	850
19	Carbon bush 12 v	Each	THAILAND	0	1200
20	Carbon holder	Each	THAILAND	0	1200
21	Carbon rocker 12v	Each	THAILAND	0	1200
22	cloth piece	per meter	THAILAND	0	10
23	collant	per litre	THAILAND	0	310
24	dash board polish	per piece	THAILAND	0	400
25	Dial wrench (6-32mm)	Set	THAILAND	0	1500
26	distilled water	per litre	THAILAND	0	45
27	Dust guard back and front	Set	THAILAND	0	2500
28	Dynamo bearing	Each	THAILAND	0	650
29	Dynamo rocker	Each	THAILAND	0	650
30	Electric horn 2v	Each	THAILAND	0	950
31	foot mat	Set	THAILAND	0	3850
32	Front bumper	Each	THAILAND	0	14500
33	fuel and water separator	per piece	THAILAND	0	20
34	fuel pipe	per piece	THAILAND	0	20
35	Fuse 10 Amp	Each	THAILAND	0	45
36	Fuse 15 Amp	Each	THAILAND	0	45
37	Fuse 20 Amp	Each	THAILAND	0	45
38	Fuse 25 Amp	Each	THAILAND	0	45
39	Fuse 30 Amp	Each	THAILAND	0	45
40	Fuse 5 Amp	Each	THAILAND	0	45
41	Glow plug	Each	THAILAND	0	4800
42	Grease	per kg	THAILAND	0	550
43	Grease gun	Each	THAILAND	0	1500

44	Head light Assy (Left)	Each	THAILAND	0	14500
45	Head light Assy (Right)	Each	THAILAND	0	14500
46	Head light bulb (Halogen)	Each	THAILAND	0	280
47	Horn high	Each	THAILAND	0	950
48	Horn low	Each	THAILAND	0	950
49	Horn relay	Each	THAILAND	0	280
50	horn switch	per piece	THAILAND	0	250
51	Hour meter	Each	THAILAND	0	25
52	Ignition switch	Each	THAILAND	0	25
53	LT wire 5mm	Each	THAILAND	0	45
54	LT wire 6mm	Each	THAILAND	0	45
55	LT wire 8mm	Each	THAILAND	0	45
56	Mobil (15w40)	per litre	THAILAND	0	450
57	nozzle pipe	per piece	THAILAND	0	1200
58	Plastic lock	Each	THAILAND	0	25
59	Plastic tape	Each	THAILAND	0	25
60	PVC tape	Each	THAILAND	0	25
61	Rain guard	Set	THAILAND	0	4800
62	Rear tail board railing	Each	THAILAND	0	120
63	Rectifier	Each	THAILAND	0	2500
64	Red paper	Each	THAILAND	0	20
65	Relay 2 pin 12v	Each	THAILAND	0	120
66	Relay 3 pin 12v	Each	THAILAND	0	120
67	Relay 4 pin 12v	Each	THAILAND	0	120
68	Relay 5 pin 12v	Each	THAILAND	0	120
69	Rotor coil	Each	THAILAND	0	120
70	seat cover	Set	THAILAND	0	9500
71	Self Armerture 12v	Each	THAILAND	0	7500
72	Self bush 12V	Each	THAILAND	0	1200
73	Self carbon 12V	Each	THAILAND	0	1200
74	Self field coil 12v	Each	THAILAND	0	120
75	Self housing	Each	THAILAND	0	6500
76	Self top cover	Each	THAILAND	0	250
77	Solonoid switch 12v	Each	THAILAND	0	250
78	Speedo meter Assy	Each	THAILAND	0	0
79	Speedo meter cable	Each	THAILAND	0	0
80	Speedo meter pinion	Each	THAILAND	0	4520
81	Starter coil	Each	THAILAND	0	250
82	Starter relay 12v	Each	THAILAND	0	25
83	steering cover	per piece	THAILAND	0	980
84	Threading tape	Each	THAILAND	0	25
85	vacuum nozzle pipe	per piece	THAILAND	0	1200
86	vehicle no. plate	per piece	THAILAND	0	450
87	wheel Drum	Each	THAILAND	0	9800
88	Wiper blade Assy	Each	THAILAND	0	950
89	Wiper motor	Each	THAILAND	0	1200
90	Wiring clip	Each	THAILAND	0	10

91	Bearing 6202	Each	THAILAND	0	250
92	Bearing 6302	Each	THAILAND	0	250
93	Benjo washer	Each	THAILAND	0	25
94	Cam shaft	Each	THAILAND	0	0
95	Cam shaft bush	Each	THAILAND	0	350
96	Cam shaft gear	Each	THAILAND	0	250
97	Connecting bearing	Each	THAILAND	0	350
98	Connecting bush	Each	THAILAND	0	200
99	Coonecting rod	Each	THAILAND	0	2500
100	Crank shaft	Each	THAILAND	0	0
101	Crank shaft oil seal	Each	THAILAND	0	780
102	Diesel filter	Each	THAILAND	0	2775
103	Drain plug	Each	THAILAND	0	280
104	Element Assy, Fuel	Each	THAILAND	0	25
105	Element sub assy, Air	Each	THAILAND	0	25
106	Engine head gasket	Each	THAILAND	0	4800
107	Engine mounting	Each	THAILAND	0	2500
108	Engine pacing	Each	THAILAND	0	850
109	Engine ring	Each	THAILAND	0	25
110	Fan belt	Each	THAILAND	0	3100
111	Feed pump Assy	Each	THAILAND	0	10
112	Fuel filter	Each	THAILAND	0	2775
113	Fuel injection overflow	Each	THAILAND	0	350
	pipe			0	
114	Fuel injector nozzel	Each	THAILAND	0	650
115	Fuel injector pipe	Each	THAILAND	0	210
116	Fuel pump Assy	Each	THAILAND	0	9800
117	Fuel pump washer	Each	THAILAND	0	25
118	Gas kit	Each	THAILAND	0	25
119	Hydraulic jack (Heavy	Each	THAILAND	0	4800
	Duty)			0	
120	Hydraulic jack (Light	Each	THAILAND	0	4800
	Duty)			0	
121	Hydraulic jack oil seal (Set	Each	THAILAND	0	25
	of 12 pcs)			0	
122	Inner door lock (R)	Each	THAILAND	0	1200
123	Inner door lock(L)	Each	THAILAND	0	1200
124	Jack lever	Each	THAILAND	0	1200
125	Main bearing	Each	THAILAND	0	2500
126	Mobil	per ltre	THAILAND	0	450
127	Mobile filter	Each	THAILAND	0	1350
128	Open end wrench set (6-	Set	THAILAND	0	1250
	32mm)			0	
129	Piston	Each	THAILAND	0	2500
130	Piston ring	Each	THAILAND	0	3000
131	Rocker Arm	Each	THAILAND	0	2500
132	Rocker shaft	Each	THAILAND	0	20

133	Silencer box	Each	THAILAND	0	250
134	Silencer pipe	Each	THAILAND	0	350
135	Socket (6mm-32mm)	Set	THAILAND	0	6500
136	Tappid cover packing	Each	THAILAND	0	3200
137	Thrust washer	Each	THAILAND	0	2500
138	Timing cover oil seal	Each	THAILAND	0	250
139	Timing belt	Each	THAILAND	0	4800
140	Timing cover	Each	THAILAND	0	250
141	Timing cover gear	Each	THAILAND	0	25
142	Valve guide	Each	THAILAND	0	350
143	Valve key	Each	THAILAND	0	250
144	Valve seal	Each	THAILAND	0	250
145	Valve spring	Each	THAILAND	0	10
146	Valve washer	Each	THAILAND	0	10
147	Wheel wrench	Each	THAILAND	0	950
148	Wiper Arm	Each	THAILAND	0	950
149	Wiper blade	Each	THAILAND	0	950
150	Wiper motor Assy	Each	THAILAND	0	2500
151	Axel lock	Each	THAILAND	0	650
152	Axel shaft	Each	THAILAND	0	1850
153	Axel shaft oil seal	Each	THAILAND	0	1800
154	Axel spacer	Each	THAILAND	0	450
155	Back gear bearing	Each	THAILAND	0	450
156	ball joint	per piece	THAILAND	0	3500
157	C.V joint	per piece	THAILAND	0	7800
158	Center bearing	Each	THAILAND	0	4800
159	Clutch cylinder (lower)	Each	THAILAND	0	6800
160	Clutch cylinder (Upper)	Each	THAILAND	0	6800
161	Clutch cylinder Assy	Each	THAILAND	0	0
162	Clutch cylinder kit	Each	THAILAND	0	0
163	Clutch kit	Each	THAILAND	0	0
164	Clutch kit box	Each	THAILAND	0	0
165	Clutch plate (Fan Type)	Each	THAILAND	0	18500
166	Clutch plate (Round Type)	Each	THAILAND	0	18500
167	Clutch relese bearing	Each	THAILAND	0	5800
168	Clutch rod	Each	THAILAND	0	580
169	Cross bearing	Each	THAILAND	0	6800
170	Cross holder	Each	THAILAND	0	2500
171	Cross propeller shaft	Each	THAILAND	0	12000
172	Crown tail assy	Each	THAILAND	0	12000
173	Fly wheel	Each	THAILAND	0	2500
174	Fly wheel ring	Each	THAILAND	0	20
175	Front hub bearing inner	Each	THAILAND	0	8800
176	Front hub bearing outer	Each	THAILAND	0	0
177	Gear box mounting	Each	THAILAND	0	250
178	Gear box oil seal	Each	THAILAND	0	1800
179	Gear box packing	Each	THAILAND	0	1800

180	Gear counter	Each	THAILAND	0	250
181	Gear oil	per litre	THAILAND	0	400
182	Gear pinion	Each	THAILAND	0	250
183	Gear pinion shaft	Each	THAILAND	0	250
184	Hubs bearing	per piece	THAILAND	0	0
185	Hubs checknut	Each	THAILAND	0	0
186	Hubs checknut lock	Each	THAILAND	0	0
187	Master cylinder	Each	THAILAND	0	25
188	Master cylinder kit	Each	THAILAND	0	25
189	Pilot bearing	Each	THAILAND	0	250
190	Pressure plate	Each	THAILAND	0	19800
191	Propeller shaft	Each	THAILAND	0	1200
192	Propeller shaft bolt	Each	THAILAND	0	320
193	Rear hub bearing inner	Each	THAILAND	0	1850
194	Rear hub bearing outer	Each	THAILAND	0	1850
195	Release bearing fork	Each	THAILAND	0	120
196	Release bearing lock	Each	THAILAND	0	235
197	Tail pinion bearing (inner)	Each	THAILAND	0	2800
198	Tail pinion bearing	Each	THAILAND	0	2800
	(Outer)			0	
199	Tail pinion checknut	Each	THAILAND	0	120
	washer			0	
200	Tail pinion checknut	Each	THAILAND	0	120
201	Tail Pinion oil seal	piece	THAILAND	0	1850
202	Top shaft bearing	Each	THAILAND	0	350
203	Wheel bearing inner	Each	THAILAND	0	1850
	(Front)			0	
204	Wheel bearing inner	Each	THAILAND	0	1200
	(Rear)			0	
205	Wheel bearing oil seal	Each	THAILAND	0	1200
	inner (Front)			0	
206	Wheel bearing oil seal	Each	THAILAND	0	1250
	inner (Rear)			0	
207	Wheel bearing outer	Each	THAILAND	0	1850
	(Front)			0	
208	Wheel bearing outer	Each	THAILAND	0	1850
	(Rear)			0	
209	Wheel cylinder	Each	THAILAND	0	4800
210	Wheel cylinder bucket	Each	THAILAND	0	0
211	Wheel nut	Each	THAILAND	0	350
212	Accelerator cable	Each	THAILAND	0	120
213	Brake Booster Assy	Each	THAILAND	0	15000
214	Brake Booster kit	Each	THAILAND	0	650
215	Brake cam	Each	THAILAND	0	250
216	Brake cam Arm	Each	THAILAND	0	120
217	Brake cam Arm lock	Each	THAILAND	0	120
218	Brake cam bush	Each	THAILAND	0	250

219	brake disc	Each	THAILAND	0	9800
220	Brake flexible pipe (Front)	Each	THAILAND	0	250
221	Brake fluid dot3	Each	THAILAND	0	550
222	brake light bulb	per piece	THAILAND	0	45
223	Brake lining	Each	THAILAND	0	0
224	Brake oil	per litres	THAILAND	0	550
225	Brake pad	Each	THAILAND	0	6800
226	Brake pipe (Rear)	Each	THAILAND	0	250
227	Brake servo	Each	THAILAND	0	25
228	Brake shoe	Each	THAILAND	0	6800
229	Brake shoe lock with	Each	THAILAND	0	250
	spring			0	
230	Break bucket	Each	THAILAND	0	20
231	Break lining back and	Each	THAILAND	0	250
	front			0	
232	Break shoe	Each	THAILAND	0	0
233	Controlling cylinder Assy	Each	THAILAND	0	250
234	Controlling pipe	Each	THAILAND	0	250
235	Controlling switch Assy	Each	THAILAND	0	350
236	Dual brake valve Assy	Each	THAILAND	0	25
237	Hand brake cable	Each	THAILAND	0	7800
238	Oil seal	Each	THAILAND	0	10
239	Spring 2nd leaf (R)	Each	THAILAND	0	8500
240	Spring 2nd leaf (F)	Each	THAILAND	0	0
241	Spring 3rd leaf ®	Each	THAILAND	0	7500
242	Spring 3rd leaf (F)	Each	THAILAND	0	0
243	Spring 4th leaf ®	Each	THAILAND	0	7500
244	Spring 4th leaf (F)	Each	THAILAND	0	0
245	Spring 5th leaf ®	Each	THAILAND	0	5500
246	Spring 5th leaf (F)	Each	THAILAND	0	0
247	Spring 6th leaf ®	Each	THAILAND	0	3500
248	Spring 6th leaf (F)	Each	THAILAND	0	0
249	Centre bolt	Each	THAILAND	0	280
250	Cycle pin	Each	THAILAND	0	380
251	Helper leaf Spring	Each	THAILAND	0	250
252	Main leaf spring (R)	Each	THAILAND	0	8500
253	Main leaf spring (F)	Each	THAILAND	0	0
254	Shock absorber	Each	THAILAND	0	8500
255	Shocker nut bolt	Each	THAILAND	0	350
256	Spring buffer mounting	Each	THAILAND	0	250
257	Spring bush	Each	THAILAND	0	280
258	Spring clamp	Each	THAILAND	0	250
259	Spring cycle pin	Each	THAILAND	0	25
260	Spring hanger	Each	THAILAND	0	25
261	Spring pin	Each	THAILAND	0	250
262	Spring shackle	Each	THAILAND	0	250
263	U bolt	Each	THAILAND	0	1800

264	U bolt nut	Each	THAILAND	0	25
265	U bolt plate	Each	THAILAND	0	25
266	Air filter	Each	THAILAND	0	2800
267	Air filter hose pipe	Each	THAILAND	0	650
268	Coolant	per litres	THAILAND	0	350
269	Exhaust manifold	Each	THAILAND	0	25
270	Hose pipe clamp	Each	THAILAND	0	150
271	Hydraulic filter	Each	THAILAND	0	250
272	Hydraulic oil	per litre	THAILAND	0	250
273	Hydraulic pipe	Each	THAILAND	0	25
274	Intake manifold	Each	THAILAND	0	350
275	Radiator assy	Each	THAILAND	0	33000
276	Radiator cap	Each	THAILAND	0	650
277	radiator hose pipe	Each	THAILAND	0	250
	(Lower)			0	
278	Radiator hose pipe	Each	THAILAND	0	250
	(Upper)			0	
279	Vacuum pipe	Each	THAILAND	0	25
280	Arm bushing lower big	Each	THAILAND	0	1850
281	Arm bushing lower small	Each	THAILAND	0	1850
282	Power steering box Assy	Each	THAILAND	0	20
283	Steering adjuster bolt	Each	THAILAND	0	25
	Assy			0	
284	Steering box oil seal	Each	THAILAND	0	4800
285	Steering column (Inner)	Each	THAILAND	0	250
286	Steering column (Outer)	Each	THAILAND	0	250
287	Steering cross	Each	THAILAND	0	8500
288	Steering cross bearing	Each	THAILAND	0	250
289	Tie rod end	Each	THAILAND	0	7800
290	Back glass	Each	THAILAND	0	19800
291	Front Windshield glass	Each	THAILAND	0	28000
292	Looking glass (R)	Each	THAILAND	0	19850
293	Looking glass (L)	Each	THAILAND	0	19850
294	Window glass	Each	THAILAND	0	20
295	Power steering bearing	Each	THAILAND	0	350
296	Power steering oil	per litres	THAILAND	0	550
297	Power steering pipe	Each	THAILAND	0	50
298	Head light assembly	Each	THAILAND	0	14800
299	Head light bulb	Each	THAILAND	0	250
300	Head light cover	Each	THAILAND	0	25
301	Indicator light	Each	THAILAND	0	45
302	Side light	Each	THAILAND	0	55
303	Gear Box Opening and	each	THAILAND	0	3500
	fitting charges			0	
304	Spring opening and fitting	each	THAILAND	0	650
	charges			0	
305	A/c filter changing	per piece	THAILAND	0	50

306	Accelerator cable	Each	THAILAND	0	25
	changing			0	
307	Air compressor leakage	Each	THAILAND	0	20
	repairing			0	
308	Air Element changing	Each	THAILAND	0	20
309	Air filter changing	Each	THAILAND	0	50
310	Air filter hose pipe	Each	THAILAND	0	25
	changing			0	
311	Air filter servicing	Each	THAILAND	0	50
312	Air tank opening &	Each	THAILAND	0	2500
	refitting			0	
313	Air unloader opening &	Each	THAILAND	0	25
	new service kit fitting			0	
314	Alternator cut out	Each	THAILAND	0	100
	changing			0	
315	Alternator overhauling	Each	THAILAND	0	1200
316	Arm bush change charges	Each	THAILAND	0	450
317	Back light assy changing	Each	THAILAND	0	50
318	Back light bulb changing	Each	THAILAND	0	50
319	ball joint changing	per piece	THAILAND	0	350
320	Battery box new making	Each	THAILAND	0	50
321	Battery cable changing	Each	THAILAND	0	50
322	Battery change	Each	THAILAND	0	50
323	Battery terminal changing	Each	THAILAND	0	50
324	Bendix pinion repairing &	Each	THAILAND	0	250
	replacing			0	
325	Brake adjuster opening &	Each	THAILAND	0	250
	refitting			0	
326	Brake cam bush opening	Each	THAILAND	0	20
	& fitting			0	
327	Brake diafam opening & new	Each	THAILAND	0	25
	service kit changing			0	
328	Brake dise cutting	Each	THAILAND	0	950
329	brake disc changing	Each	THAILAND	0	450
330	Brake drum cutting	Each	THAILAND	0	850
331	Brake dual valve kit	Each	THAILAND	0	25
	changing			0	
332	Brake flexible pipe	Each	THAILAND	0	250
	changing			0	
333	Brake linning changing	Each	THAILAND	0	25
334	brake pipe bleasting	each	THAILAND	0	25
335	Brake pipe changing	Each	THAILAND	0	35
336	Brake pipe leakage	Each	THAILAND	0	350
	repairing			0	
337	Brake servo Changing	Each	THAILAND	0	20
338	Brake servo repairing &	Each	THAILAND	0	20
	servicing			0	

339	Brake Shoe Changing	Each	THAILAND	0	300
340	Brass blezzing	Each	THAILAND	0	20
341	Carbon soldering	Each	THAILAND	0	200
342	Center bearing changing	Each	THAILAND	0	350
343	Clutch plate changing	Each	THAILAND	0	1200
344	Clutch release bearing	Each	THAILAND	0	1200
	changing			0	
345	Coil Spring changing	Each	THAILAND	0	25
346	collant change	Each	THAILAND	0	250
347	Controlling overhauling	Each	THAILAND	0	250
348	Controlling pipe changing	Each	THAILAND	0	250
349	Cross bearing changing	Each	THAILAND	0	450
350	Cross bearing greasing	Each	THAILAND	0	450
351	Cross Coupling cutting by	each	THAILAND	0	25
	lath machine			0	
352	Cross holder cutting and	Each	THAILAND	0	250
	welding			0	
353	Crown Overhauling	Each	THAILAND	0	2500
354	CV joint changing	per piece	THAILAND	0	25
355	Cycle pin changing	Each	THAILAND	0	25
356	denting and painting	per mtre	THAILAND	0	150
357	Door lock new making	Each	THAILAND	0	250
358	Dynamo bearing changing	Each	THAILAND	0	250
359	Electric welding	Each	THAILAND	0	25
360	Engine head gasket	Each	THAILAND	0	1500
	changing			0	
361	Engine mount changing	Each	THAILAND	0	120
362	Engine oil changing	Each	THAILAND	0	350
363	Engine Twining	Each	THAILAND	0	25
364	Engine water pump	Each	THAILAND	0	350
	changing			0	
365	Fan belt bearing	Each	THAILAND	0	25
	changing			0	
366	Fan belt changing	Each	THAILAND	0	650
367	Feed pump assy changing	Each	THAILAND	0	25
368	Feed pump repairing	Each	THAILAND	0	25
369	Fly wheel changing	Each	THAILAND	0	350
370	Fly wheel changing	Each	THAILAND	0	350
371	Fly wheel poolishing	Each	THAILAND	0	25
372	fuel and water separator	each	THAILAND	0	250
	cchanging			0	
373	Fuel filter changing	Each	THAILAND	0	350
374	Fuel injection pump	Each	THAILAND	0	250
	opening & fitting			0	
375	Fuel over flow pipe	Each	THAILAND	0	320
	changing			0	
376	fuel pipe changing	each	THAILAND	0	250

377	Fuel tank opening &	Each	THAILAND	0	2500
	fitting			0	
378	Fuel tank servicing	Each	THAILAND	0	1500
379	Full Engine Overhauling	Each	THAILAND	0	4500
380	Gear oil changing	Each	THAILAND	0	300
381	Gear shaft changing	Each	THAILAND	0	25
382	Gear shaft polishing	Each	THAILAND	0	25
383	Half Engine Overhauling	Each	THAILAND	0	2500
384	Head light assy changing	Each	THAILAND	0	100
385	Head light bulb fitting	Each	THAILAND	0	100
386	horn and switch fitting	per set	THAILAND	0	25
387	Horn fitting	Each	THAILAND	0	250
388	Horn relay fitting	Each	THAILAND	0	50
389	Hub greasing (Fr)	Each	THAILAND	0	10
390	Hub greasing (Rear)	Each	THAILAND	0	10
391	hubs bearing changing	per piece	THAILAND	0	650
392	Hydraulic control valve	Each	THAILAND	0	20
	opening servicing & refitting			0	
393	Hydraulic filter changing	Each	THAILAND	0	20
394	Hydraulic hose pipe	Each	THAILAND	0	20
	changing			0	
395	Hydraulic oil changing	Each	THAILAND	0	20
396	Hydraulic pipe changing	Each	THAILAND	0	20
397	Hydraulic pipe leakage	Each	THAILAND	0	20
	repairing			0	
398	Hydraulic pump & pipe	Each	THAILAND	0	20
	line new fitting			0	
399	Hydraulic tank servicing	Each	THAILAND	0	20
400	Ignition switch changing	Each	THAILAND	0	20
401	Inner wheel bearing	Each	THAILAND	0	650
	changing (Fr)			0	
402	Inner wheel bearing	Each	THAILAND	0	10
	changing (Rear)			0	
403	Inner wheel bearing oil	Each	THAILAND	0	650
	seal changing (Fr)			0	
404	Inner wheel bearing oil	Each	THAILAND	0	10
	seal changing (Rear)			0	
405	King pin bush machinery	Each	THAILAND	0	10
	cutting both side			0	
406	King pin overhauling	Each	THAILAND	0	10
	bothside			0	
407	KM cable changing &	Each	THAILAND	0	100
	refitting			0	
408	Lower clutch kit changing	Each	THAILAND	0	100
409	Lower Radiator hose pipe	Each	THAILAND	0	100
	changing			0	
410	Master cylinder changing	Each	THAILAND	0	10

411	Master cylinder kit	Each	THAILAND	0	10
	changing			0	
412	Master cylinder repairing	Each	THAILAND	0	10
413	mobile filter changing	Each	THAILAND	0	25
414	Number Plate change	Each	THAILAND	0	350
415	Outer wheel bearing	Each	THAILAND	0	350
	changing (Fr)			0	
416	Outer wheel bearing	Each	THAILAND	0	25
	changing (Rear)			0	
417	Outer wheel bearing oil	Each	THAILAND	0	250
	seal changing (Fr)			0	
418	Outer wheel bearing oil	Each	THAILAND	0	250
	seal changing (Rear)			0	
419	Power steering	Each	THAILAND	0	250
	overhauling			0	
420	Power steering pump	Each	THAILAND	0	350
	change			0	
421	Pressure plate changing	Each	THAILAND	0	1200
422	Pressure water pump removal, refitting and	Each	THAILAND	0	25
	gasket changing			0	
423	Propeller shaft yolk	Each	THAILAND	0	350
	changing			0	
424	PTO bracket new making	Each	THAILAND	0	250
425	PTO bracket removal	Each	THAILAND	0	20
426	PTO pump servicing	Each	THAILAND	0	10
427	Quarter pin changing	Each	THAILAND	0	10
428	Radiator assy changing	Each	THAILAND	0	850
429	Radiator repairing &	Each	THAILAND	0	3500
	servicing			0	
430	Rain guard fitting	Each	THAILAND	0	100
431	Rear bumper open	Each	THAILAND	0	650
	fitting and welding			0	
432	Rear hydraulic jack opening & new seal kit	Each	THAILAND	0	350
	fitting			0	
433	recovery van hiring	Per Km	THAILAND	0	20
	charges			0	
434	Release bearing changing	Each	THAILAND	0	1200
435	Release bearing fork	Each	THAILAND	0	1200
	changing			0	
436	Release bearing lock	Each	THAILAND	0	25
	changing			0	
437	Seal kit changing	Each	THAILAND	0	25
438	Seat new making	Set	THAILAND	0	0
439	Self Bush changing	Each	THAILAND	0	120
440	Self carbon changing	Each	THAILAND	0	450

441	Self Overhauling	Each	THAILAND	0	1250
442	Self rewinding	Each	THAILAND	0	1200
443	Shock absorber changing	Each	THAILAND	0	650
444	Side door glass changing	Each	THAILAND	0	250
445	Solonoid switch changing	Each	THAILAND	0	120
446	Spring buffer mounting	Each	THAILAND	0	25
	changing			0	
447	Spring bush changing	Each	THAILAND	0	100
448	spring clam welding	per piece	THAILAND	0	100
449	Spring clam changing	Each	THAILAND	0	100
450	Spring hanger changing	Each	THAILAND	0	100
451	Spring pin bush changing	Each	THAILAND	0	120
452	Spring Shackle pin	Each	THAILAND	0	120
	changing			0	
453	Steering box kit changing	Each	THAILAND	0	20
454	Steering box oil seal	Each	THAILAND	0	2500
	changing			0	
455	Steering box overhauling	Each	THAILAND	0	2500
456	Steering Column changing	Each	THAILAND	0	450
	(inner)			0	
457	Steering Column changing	Each	THAILAND	0	450
	(Outer)			0	
458	Steering cross bearing	Each	THAILAND	0	450
	changing			0	
459	Steering cross changing	Each	THAILAND	0	450
460	Steering rack changing	Each	THAILAND	0	650
461	Steering wheel opening &	Each	THAILAND	0	120
	refitting			0	
462	Tail pinion oil seal change	Each	THAILAND	0	120
463	Tailgate Repairing	Each	THAILAND	0	120
464	Tappet adjusting	Each	THAILAND	0	120
465	Tie rod end changing	Each	THAILAND	0	250
466	Tie rod kit changing	Each	THAILAND	0	250
467	Timing belt changing	Each	THAILAND	0	350
468	Timing cover gear	Each	THAILAND	0	120
	changing			0	
469	Transmission half	Each	THAILAND	0	120
	overhauling			0	
470	Transmission over hauling	Each	THAILAND	0	120
471	U bolt changing	Each	THAILAND	0	120
472	Upper clutch kit changing	Each	THAILAND	0	120
473	Upper Radiator hose pipe	Each	THAILAND	0	150
	changing			0	
474	Vaccum pipe changing	Each	THAILAND	0	150
475	vacuum nozzle pipe	each	THAILAND	0	150
	changing			0	
476	Vacuum pipe socket	Each	THAILAND	0	120

476	changing	Each	THAILAND	0	120
477	Valve O ring changing	Each	THAILAND	0	120
478	Valve oil seal changing	Each	THAILAND	0	120
479	Valve spring changing	Each	THAILAND	0	120
480	Water filter changing	Each	THAILAND	0	20
481	Water level indicator pipe	Each	THAILAND	0	20
	changing			0	
482	Water pump assy	Each	THAILAND	0	200
	servicing			0	
483	Water separator changing	Each	THAILAND	0	200
484	Water separator servicing	Each	THAILAND	0	200
485	Wind shield replacing	Each	THAILAND	0	1200
486	Wiper arm changing	Each	THAILAND	0	10
487	Wiper blade changing	Each	THAILAND	0	20
488	Wiper motor changing	Each	THAILAND	0	20
489	Wiper motor repairing	Each	THAILAND	0	200