

				Kuenzom Automobiles	Lungten Automobiles
Sl. No	Discription	Unit	Country of origin	Rate	Rate
1	Battery terminal end	Each	THAILAND	50	0
2	A/C filter	per piece	THAILAND	20	0
3	Alternator Assy	Each	THAILAND	14500	0
4	Alternator carbon bush	Each	THAILAND	120	0
5	Alternator cut out	Each	THAILAND	1250	0
6	Anabond paste (Big)	Each	THAILAND	350	0
7	Anabond paste (Small)	Each	THAILAND	90	0
8	Back bumper	Each	THAILAND	3500	0
9	Back light Assy (Left)	Each	THAILAND	980	0
10	Back light Assy (Right)	Each	THAILAND	980	0
11	Battery cable +ive	Each	THAILAND	150	0
12	Battery cable -ive	Each	THAILAND	150	0
13	Bendix pinion	Each	THAILAND	4500	0
14	Black tape	per piece	THAILAND	30	0
15	Brake light switch	Each	THAILAND	350	0
16	Bulb 1141	Each	THAILAND	20	0
17	Bulb 67	Each	THAILAND	20	0
18	bush stabilzer	per piece	THAILAND	220	0
19	Carbon bush 12 v	Each	THAILAND	950	0
20	Carbon holder	Each	THAILAND	750	0
21	Carbon rocker 12v	Each	THAILAND	250	0
22	cloth piece	per meter	THAILAND	10	0
23	collant	per litre	THAILAND	223	0
24	dash board polish	per piece	THAILAND	300	0
25	Dial wrench (6-32mm)	Set	THAILAND	120	0
26	distilled water	per litre	THAILAND	35	0
27	Dust guard back and front	Set	THAILAND	850	0
28	Dynamo bearing	Each	THAILAND	550	0
29	Dynamo rocker	Each	THAILAND	950	0
30	Electric horn 2v	Each	THAILAND	850	0
31	foot mat	Set	THAILAND	2950	0
32	Front bumper	Each	THAILAND	5500	0
33	fuel and water separator	per piece	THAILAND	450	0
34	fuel pipe	per piece	THAILAND	650	0
35	Fuse 10 Amp	Each	THAILAND	5	0
36	Fuse 15 Amp	Each	THAILAND	5	0
37	Fuse 20 Amp	Each	THAILAND	5	0
38	Fuse 25 Amp	Each	THAILAND	5	0
39	Fuse 30 Amp	Each	THAILAND	5	0
40	Fuse 5 Amp	Each	THAILAND	5	0
41	Glow plug	Each	THAILAND	1800	0
42	Grease	per kg	THAILAND	300	0
43	Grease gun	Each	THAILAND	750	0
44	Head light Assy (Left)	Each	THAILAND	1250	0
45	Head light Assy (Right)	Each	THAILAND	1250	0
46	Head light bulb (Halogen)	Each	THAILAND	150	0
47	Horn high	Each	THAILAND	850	0

48	Horn low	Each	THAILAND	850	0
49	Horn relay	Each	THAILAND	350	0
50	horn switch	per piece	THAILAND	550	0
51	Hour meter	Each	THAILAND	20	0
52	Ignition switch	Each	THAILAND	890	0
53	LT wire 5mm	Each	THAILAND	45	0
54	LT wire 6mm	Each	THAILAND	45	0
55	LT wire 8mm	Each	THAILAND	55	0
56	Mobil (15w40)	per litre	THAILAND	400	0
57	nozzle pipe	per piece	THAILAND	650	0
58	Plastic lock	Each	THAILAND	10	0
59	Plastic tape	Each	THAILAND	30	0
60	PVC tape	Each	THAILAND	20	0
61	Rain guard	Set	THAILAND	2200	0
62	Rear tail board railing	Each	THAILAND	20	0
63	Rectifier	Each	THAILAND	4500	0
64	Red paper	Each	THAILAND	15	0
65	Relay 2 pin 12v	Each	THAILAND	350	0
66	Relay 3 pin 12v	Each	THAILAND	250	0
67	Relay 4 pin 12v	Each	THAILAND	350	0
68	Relay 5 pin 12v	Each	THAILAND	550	0
69	Rotor coil	Each	THAILAND	5500	0
70	seat cover	Set	THAILAND	7000	0
71	Self Armerture 12v	Each	THAILAND	2200	0
72	Self bush 12V	Each	THAILAND	150	0
73	Self carbon 12V	Each	THAILAND	760	0
74	Self field coil 12v	Each	THAILAND	4500	0
75	Self housing	Each	THAILAND	6500	0
76	Self top cover	Each	THAILAND	1250	0
77	Solonoid switch 12v	Each	THAILAND	20	0
78	Speedo meter Assy	Each	THAILAND	1800	0
79	Speedo meter cable	Each	THAILAND	1600	0
80	Speedo meter pinion	Each	THAILAND	20	0
81	Starter coil	Each	THAILAND	3300	0
82	Starter relay 12v	Each	THAILAND	450	0
83	steering cover	per piece	THAILAND	950	0
84	Threading tape	Each	THAILAND	50	0
85	vacuum nozzle pipe	per piece	THAILAND	550	0
86	vehicle no. plate	per piece	THAILAND	400	0
87	wheel Drum	Each	THAILAND	4500	0
88	Wiper blade Assy	Each	THAILAND	650	0
89	Wiper motor	Each	THAILAND	1250	0
90	Wiring clip	Each	THAILAND	10	0
91	Bearing 6202	Each	THAILAND	350	0
92	Bearing 6302	Each	THAILAND	450	0
93	Benjo washer	Each	THAILAND	10	0
94	Cam shaft	Each	THAILAND	8500	0
95	Cam shaft bush	Each	THAILAND	350	0
96	Cam shaft gear	Each	THAILAND	1250	0
97	Connecting bearing	Each	THAILAND	2200	0
98	Connecting bush	Each	THAILAND	350	0

99	Coonecting rod	Each	THAILAND	10	0
100	Crank shaft	Each	THAILAND	75000	0
101	Crank shaft oil seal	Each	THAILAND	650	0
102	Diesel filter	Each	THAILAND	1850	0
103	Drain plug	Each	THAILAND	10	0
104	Element Assy, Fuel	Each	THAILAND	1250	0
105	Element sub assy, Air	Each	THAILAND	850	0
106	Engine head gasket	Each	THAILAND	2200	0
107	Engine mounting	Each	THAILAND	1260	0
108	Engine pacing	Each	THAILAND	20	0
109	Engine ring	Each	THAILAND	10	0
110	Fan belt	Each	THAILAND	1800	0
111	Feed pump Assy	Each	THAILAND	1600	0
112	Fuel filter	Each	THAILAND	550	0
113	Fuel injection overflow pipe	Each	THAILAND	1250	0
114	Fuel injector nozzel	Each	THAILAND	10	0
115	Fuel injector pipe	Each	THAILAND	20	0
116	Fuel pump Assy	Each	THAILAND	20	0
117	Fuel pump washer	Each	THAILAND	10	0
118	Gas kit	Each	THAILAND	10	0
119	Hydraulic jack (Heavy Duty)	Each	THAILAND	9500	0
120	Hydraulic jack (Light Duty)	Each	THAILAND	5500	0
121	Hydraulic jack oil seal (Set of 12 pcs)	Each	THAILAND	3500	0
122	Inner door lock (R)	Each	THAILAND	450	0
123	Inner door lock(L)	Each	THAILAND	450	0
124	Jack lever	Each	THAILAND	350	0
125	Main bearing	Each	THAILAND	3950	0
126	Mobil	per litre	THAILAND	400	0
127	Mobile filter	Each	THAILAND	750	0
128	Open end wrench set (6- 32mm)	Set	THAILAND	459	0
129	Piston	Each	THAILAND	8500	0
130	Piston ring	Each	THAILAND	1200	0
131	Rocker Arm	Each	THAILAND	850	0
132	Rocker shaft	Each	THAILAND	750	0
133	Silencer box	Each	THAILAND	5500	0
134	Silencer pipe	Each	THAILAND	5000	0
135	Socket (6mm-32mm)	Set	THAILAND	250	0
136	Tappid cover packing	Each	THAILAND	20	0
137	Thrust washer	Each	THAILAND	850	0
138	Timing cover oil seal	Each	THAILAND	550	0
139	Timing belt	Each	THAILAND	2200	0
140	Timing cover	Each	THAILAND	20	0
141	Timing cover gear	Each	THAILAND	350	0
142	Valve guide	Each	THAILAND	450	0
143	Valve key	Each	THAILAND	450	0

144	Valve seal	Each	THAILAND	450	0
145	Valve spring	Each	THAILAND	450	0
146	Valve washer	Each	THAILAND	20	0
147	Wheel wrench	Each	THAILAND	450	0
148	Wiper Arm	Each	THAILAND	1250	0
149	Wiper blade	Each	THAILAND	650	0
150	Wiper motor Assy	Each	THAILAND	550	0
151	Axel lock	Each	THAILAND	10	0
152	Axel shaft	Each	THAILAND	12500	0
153	Axel shaft oil seal	Each	THAILAND	450	0
154	Axel spacer	Each	THAILAND	10	0
155	Back gear bearing	Each	THAILAND	20	0
156	ball joint	per piece	THAILAND	2200	0
157	C.V joint	per piece	THAILAND	20	0
158	Center bearing	Each	THAILAND	2200	0
159	Clutch cylinder (lower)	Each	THAILAND	2200	0
160	Clutch cylinder (Upper)	Each	THAILAND	3500	0
161	Clutch cylinder Assy	Each	THAILAND	9500	0
162	Clutch cylinder kit	Each	THAILAND	20	0
163	Clutch kit	Each	THAILAND	20	0
164	Clutch kit box	Each	THAILAND	20	0
165	Clutch plate (Fan Type)	Each	THAILAND	12500	0
166	Clutch plate (Round Type)	Each	THAILAND	13500	0
167	Clutch relese bearing	Each	THAILAND	2800	0
168	Clutch rod	Each	THAILAND	20	0
169	Cross bearing	Each	THAILAND	3500	0
170	Cross holder	Each	THAILAND	10	0
171	Cross propeller shaft	Each	THAILAND	20	0
172	Crown tail assy	Each	THAILAND	18500	0
173	Fly wheel	Each	THAILAND	20	0
174	Fly wheel ring	Each	THAILAND	680	0
175	Front hub bearing inner	Each	THAILAND	1850	0
176	Front hub bearing outer	Each	THAILAND	1750	0
177	Gear box mounting	Each	THAILAND	1250	0
178	Gear box oil seal	Each	THAILAND	550	0
179	Gear box packing	Each	THAILAND	20	0
180	Gear counter	Each	THAILAND	9500	0
181	Gear oil	per litre	THAILAND	300	0
182	Gear pinion	Each	THAILAND	5500	0
183	Gear pinion shaft	Each	THAILAND	7500	0
184	Hubs bearing	per piece	THAILAND	1850	0
185	Hubs checknut	Each	THAILAND	1750	0
186	Hubs checknut lock	Each	THAILAND	120	0
187	Master cylinder	Each	THAILAND	7400	0
188	Master cylinder kit	Each	THAILAND	350	0
189	Pilot bearing	Each	THAILAND	550	0
190	Pressure plate	Each	THAILAND	7500	0
191	Propeller shaft	Each	THAILAND	12500	0
192	Propeller shaft bolt	Each	THAILAND	20	0
193	Rear hub bearing inner	Each	THAILAND	1250	0
194	Rear hub bearing outer	Each	THAILAND	1250	0

195	Release bearing fork	Each	THAILAND	2200	0
196	Release bearing lock	Each	THAILAND	20	0
197	Tail pinion bearing (inner)	Each	THAILAND	950	0
198	Tail pinion bearing (Outer)	Each	THAILAND	650	0
199	Tail pinion chechnut washer	Each	THAILAND	20	0
200	Tail pinion checknut	Each	THAILAND	20	0
201	Tail Pinion oil seal	piece	THAILAND	550	0
202	Top shaft bearing	Each	THAILAND	550	0
203	Wheel bearing inner (Front)	Each	THAILAND	1850	0
204	Wheel bearing inner (Rear)	Each	THAILAND	1750	0
205	Wheel bearing oil seal inner (Front)	Each	THAILAND	550	0
206	Wheel bearing oil seal inner (Rear)	Each	THAILAND	550	0
207	Wheel bearing outer (Front)	Each	THAILAND	1850	0
208	Wheel bearing outer (Rear)	Each	THAILAND	1750	0
209	Wheel cylinder	Each	THAILAND	4500	0
210	Wheel cylinder bucket	Each	THAILAND	120	0
211	Wheel nut	Each	THAILAND	250	0
212	Accelerator cable	Each	THAILAND	1200	0
213	Brake Booster Assy	Each	THAILAND	5500	0
214	Brake Booster kit	Each	THAILAND	350	0
215	Brake cam	Each	THAILAND	20	0
216	Brake cam Arm	Each	THAILAND	20	0
217	Brake cam Arm lock	Each	THAILAND	20	0
218	Brake cam bush	Each	THAILAND	20	0
219	brake disc	Each	THAILAND	3500	0
220	Brake flexible pipe (Front)	Each	THAILAND	450	0
221	Brake fluid dot3	Each	THAILAND	550	0
222	brake light bulb	per piece	THAILAND	20	0
223	Brake lining	Each	THAILAND	5500	0
224	Brake oil	per litres	THAILAND	550	0
225	Brake pad	Each	THAILAND	20	0
226	Brake pipe (Rear)	Each	THAILAND	350	0
227	Brake servo	Each	THAILAND	20	0
228	Brake shoe	Each	THAILAND	20	0
229	Brake shoe lock with spring	Each	THAILAND	20	0
230	Break bucket	Each	THAILAND	120	0
231	Break lining back and front	Each	THAILAND	20	0
232	Break shoe	Each	THAILAND	6500	0
233	Controlling cylinder Assy	Each	THAILAND	2500	0
234	Controlling pipe	Each	THAILAND	120	0

235	Controlling switch Assy	Each	THAILAND	550	0
236	Dual brake valve Assy	Each	THAILAND	12500	0
237	Hand brake cable	Each	THAILAND	2200	0
238	Oil seal	Each	THAILAND	550	0
239	Spring 2nd leaf (R)	Each	THAILAND	1800	0
240	Spring 2nd leaf (F)	Each	THAILAND	1800	0
241	Spring 3rd leaf ®	Each	THAILAND	1800	0
242	Spring 3rd leaf (F)	Each	THAILAND	1800	0
243	Spring 4th leaf ®	Each	THAILAND	1800	0
244	Spring 4th leaf (F)	Each	THAILAND	1800	0
245	Spring 5th leaf ®	Each	THAILAND	1800	0
246	Spring 5th leaf (F)	Each	THAILAND	1600	0
247	Spring 6th leaf ®	Each	THAILAND	1600	0
248	Spring 6th leaf (F)	Each	THAILAND	1200	0
249	Centre bolt	Each	THAILAND	50	0
250	Cycle pin	Each	THAILAND	250	0
251	Helper leaf Spring	Each	THAILAND	1100	0
252	Main leaf spring (R)	Each	THAILAND	2200	0
253	Main leaf spring (F)	Each	THAILAND	1800	0
254	Shock absorber	Each	THAILAND	20	0
255	Shocker nut bolt	Each	THAILAND	250	0
256	Spring buffer mounting	Each	THAILAND	550	0
257	Spring bush	Each	THAILAND	180	0
258	Spring clamp	Each	THAILAND	350	0
259	Spring cycle pin	Each	THAILAND	350	0
260	Spring hanger	Each	THAILAND	850	0
261	Spring pin	Each	THAILAND	350	0
262	Spring shackle	Each	THAILAND	350	0
263	U bolt	Each	THAILAND	350	0
264	U bolt nut	Each	THAILAND	250	0
265	U bolt plate	Each	THAILAND	240	0
266	Air filter	Each	THAILAND	890	0
267	Air filter hose pipe	Each	THAILAND	350	0
268	Coolant	per litres	THAILAND	223	0
269	Exhaust manifold	Each	THAILAND	15500	0
270	Hose pipe clamp	Each	THAILAND	250	0
271	Hydraulic filter	Each	THAILAND	850	0
272	Hydraulic oil	per litre	THAILAND	550	0
273	Hydraulic pipe	Each	THAILAND	860	0
274	Intake manifold	Each	THAILAND	14500	0
275	Radiator assy	Each	THAILAND	15500	0
276	Radiator cap	Each	THAILAND	450	0
277	radiator hose pipe (Lower)	Each	THAILAND	1250	0
278	Radiator hose pipe (Upper)	Each	THAILAND	1250	0
279	Vacuum pipe	Each	THAILAND	2200	0
280	Arm bushing lower big	Each	THAILAND	10	0
281	Arm bushing lower small	Each	THAILAND	10	0
282	Power steering box Assy	Each	THAILAND	19000	0
283	Steering adjuster bolt	Each	THAILAND	250	0

283	Assy	Each	THAILAND	250	0
284	Steering box oil seal	Each	THAILAND	650	0
285	Steering column (Inner)	Each	THAILAND	10	0
286	Steering column (Outer)	Each	THAILAND	10	0
287	Steering cross	Each	THAILAND	2200	0
288	Steering cross bearing	Each	THAILAND	1800	0
289	Tie rod end	Each	THAILAND	2700	0
290	Back glass	Each	THAILAND	2700	0
291	Front Windshield glass	Each	THAILAND	9800	0
292	Looking glass (R)	Each	THAILAND	1800	0
293	Looking glass (L)	Each	THAILAND	1800	0
294	Window glass	Each	THAILAND	3500	0
295	Power steering bearing	Each	THAILAND	1200	0
296	Power steering oil	per litres	THAILAND	550	0
297	Power steering pipe	Each	THAILAND	2200	0
298	Head light assembly	Each	THAILAND	1250	0
299	Head light bulb	Each	THAILAND	150	0
300	Head light cover	Each	THAILAND	10	0
301	Indicator light	Each	THAILAND	250	0
302	Side light	Each	THAILAND	1100	0
303	Gear Box Opening and fitting charges	each	THAILAND	2500	0
304	Spring opening and fitting charges	each	THAILAND	450	0
305	A/c filter changing	per piece	THAILAND	10	0
306	Accelerator cable changing	Each	THAILAND	250	0
307	Air compressor leakage repairing	Each	THAILAND	20	0
308	Air Element changing	Each	THAILAND	10	0
309	Air filter changing	Each	THAILAND	20	0
310	Air filter hose pipe changing	Each	THAILAND	250	0
311	Air filter servicing	Each	THAILAND	10	0
312	Air tank opening & refitting	Each	THAILAND	450	0
313	Air unloader opening & new service kit fitting	Each	THAILAND	200	0
314	Alternator cut out changing	Each	THAILAND	750	0
315	Alternator overhauling	Each	THAILAND	1200	0
316	Arm bush change charges	Each	THAILAND	20	0
317	Back light assy changing	Each	THAILAND	10	0
318	Back light bulb changing	Each	THAILAND	20	0
319	ball joint changing	per piece	THAILAND	20	0
320	Battery box new making	Each	THAILAND	100	0
321	Battery cable changing	Each	THAILAND	200	0
322	Battery change	Each	THAILAND	20	0
323	Battery terminal changing	Each	THAILAND	20	0
324	Bendix pinion repairing & replacing	Each	THAILAND	350	0

325	Brake adjuster opening & refitting	Each	THAILAND	350	0
326	Brake cam bush opening & fitting	Each	THAILAND	250	0
327	Brake diafam opening & new service kit changing	Each	THAILAND	250	0
328	Brake disc cutting	Each	THAILAND	950	0
329	brake disc changing	Each	THAILAND	200	0
330	Brake drum cutting	Each	THAILAND	950	0
331	Brake dual valve kit changing	Each	THAILAND	200	0
332	Brake flexible pipe changing	Each	THAILAND	20	0
333	Brake linning changing	Each	THAILAND	10	0
334	brake pipe bleasting	each	THAILAND	20	0
335	Brake pipe changing	Each	THAILAND	200	0
336	Brake pipe leakage repairing	Each	THAILAND	350	0
337	Brake servo Changing	Each	THAILAND	200	0
338	Brake servo repairing & servicing	Each	THAILAND	1200	0
339	Brake Shoe Changing	Each	THAILAND	200	0
340	Brass blezzing	Each	THAILAND	10	0
341	Carbon soldering	Each	THAILAND	550	0
342	Center bearing changing	Each	THAILAND	150	0
343	Clutch plate changing	Each	THAILAND	1200	0
344	Clutch release bearing changing	Each	THAILAND	1200	0
345	Coil Spring changing	Each	THAILAND	20	0
346	collant change	Each	THAILAND	10	0
347	Controlling overhauling	Each	THAILAND	850	0
348	Controlling pipe changing	Each	THAILAND	20	0
349	Cross bearing changing	Each	THAILAND	250	0
350	Cross bearing greasing	Each	THAILAND	20	0
351	Cross Coupling cutting by lath machine	each	THAILAND	20	0
352	Cross holder cutting and welding	Each	THAILAND	10	0
353	Crown Overhauling	Each	THAILAND	1200	0
354	CV joint changing	per piece	THAILAND	20	0
355	Cycle pin changing	Each	THAILAND	20	0
356	denting and painting	per mtre	THAILAND	5	0
357	Door lock new making	Each	THAILAND	200	0
358	Dynamo bearing changing	Each	THAILAND	200	0
359	Electric welding	Each	THAILAND	10	0
360	Engine head gasket changing	Each	THAILAND	1500	0
361	Engine mount changing	Each	THAILAND	200	0
362	Engine oil changing	Each	THAILAND	200	0
363	Engine Twining	Each	THAILAND	250	0

364	Engine water pump changing	Each	THAILAND	250	0
365	Fan belt bearing changing	Each	THAILAND	250	0
366	Fan belt changing	Each	THAILAND	250	0
367	Feed pump assy changing	Each	THAILAND	300	0
368	Feed pump repairing	Each	THAILAND	550	0
369	Fly wheel changing	Each	THAILAND	450	0
370	Fly wheel changing	Each	THAILAND	250	0
371	Fly wheel poolishing	Each	THAILAND	700	0
372	fuel and water separator cchanging	each	THAILAND	200	0
373	Fuel filter changing	Each	THAILAND	20	0
374	Fuel injection pump opening & fitting	Each	THAILAND	150	0
375	Fuel over flow pipe changing	Each	THAILAND	100	0
376	fuel pipe changing	each	THAILAND	250	0
377	Fuel tank opening & fitting	Each	THAILAND	450	0
378	Fuel tank servicing	Each	THAILAND	800	0
379	Full Engine Overhauling	Each	THAILAND	2500	0
380	Gear oil changing	Each	THAILAND	100	0
381	Gear shaft changing	Each	THAILAND	450	0
382	Gear shaft polishing	Each	THAILAND	650	0
383	Half Engine Overhauling	Each	THAILAND	1200	0
384	Head light assy changing	Each	THAILAND	20	0
385	Head light bulb fitting	Each	THAILAND	20	0
386	horn and switch fitting	per set	THAILAND	350	0
387	Horn fitting	Each	THAILAND	350	0
388	Horn relay fitting	Each	THAILAND	20	0
389	Hub greasing (Fr)	Each	THAILAND	250	0
390	Hub greasing (Rear)	Each	THAILAND	250	0
391	hubs bearing changing	per piece	THAILAND	250	0
392	Hydraulic control valve opening servicing & refitting	Each	THAILAND	150	0
393	Hydraulic filter changing	Each	THAILAND	250	0
394	Hydraulic hose pipe changing	Each	THAILAND	200	0
395	Hydraulic oil changing	Each	THAILAND	200	0
396	Hydraulic pipe changing	Each	THAILAND	150	0
397	Hydraulic pipe leakage repairing	Each	THAILAND	350	0
398	Hydraulic pump & pipe line new fitting	Each	THAILAND	350	0
399	Hydraulic tank servicing	Each	THAILAND	550	0
400	Ignition switch changing	Each	THAILAND	120	0
401	Inner wheel bearing changing (Fr)	Each	THAILAND	250	0
402	Inner wheel bearing	Each	THAILAND	250	0

402	changing (Rear)	Each	THAILAND	250	0
403	Inner wheel bearing oil	Each	THAILAND	360	0
	seal changing (Fr)				
404	Inner wheel bearing oil	Each	THAILAND	350	0
	seal changing (Rear)				
405	King pin bush machinery	Each	THAILAND	1200	0
	cutting both side				
406	King pin overhauling	Each	THAILAND	1200	0
	bothside				
407	KM cable changing &	Each	THAILAND	950	0
	refitting				
408	Lower clutch kit changing	Each	THAILAND	200	0
409	Lower Radiator hose pipe	Each	THAILAND	250	0
	changing				
410	Master cylinder changing	Each	THAILAND	200	0
411	Master cylinder kit	Each	THAILAND	200	0
	changing				
412	Master cylinder repairing	Each	THAILAND	650	0
413	mobile filter changing	Each	THAILAND	20	0
414	Number Plate change	Each	THAILAND	10	0
415	Outer wheel bearing	Each	THAILAND	200	0
	changing (Fr)				
416	Outer wheel bearing	Each	THAILAND	200	0
	changing (Rear)				
417	Outer wheel bearing oil	Each	THAILAND	200	0
	seal changing (Fr)				
418	Outer wheel bearing oil	Each	THAILAND	200	0
	seal changing (Rear)				
419	Power steering	Each	THAILAND	1200	0
	overhauling				
420	Power steering pump	Each	THAILAND	200	0
	change				
421	Pressure plate changing	Each	THAILAND	1200	0
422	Pressure water pump	Each	THAILAND	450	0
	removal, refitting and				
423	gasket changing	Each	THAILAND	200	0
	Propeller shaft york				
424	changing	Each	THAILAND	250	0
	PTO bracket new making				
425	PTO bracket removal	Each	THAILAND	550	0
426	PTO pump servicing	Each	THAILAND	800	0
427	Quarter pin changing	Each	THAILAND	20	0
428	Radiator assy changing	Each	THAILAND	230	0
429	Radiator repairing &	Each	THAILAND	20	0
	servicing				
430	Rain guard fitting	Each	THAILAND	350	0
431	Rear bumpeer open	Each	THAILAND	450	0
	fitting and welding				
432	Rear hydraulic jack opening	Each	THAILAND	360	0
	& new seal kit				
	fitting				

433	recovery van hiring	Per Km	THAILAND	0	0
	charges				
434	Release bearing changing	Each	THAILAND	1200	0
435	Release bearing fork	Each	THAILAND	300	0
	changing				
436	Release bearing lock	Each	THAILAND	200	0
	changing				
437	Seal kit changing	Each	THAILAND	200	0
438	Seat new making	Set	THAILAND	350	0
439	Self Bush changing	Each	THAILAND	450	0
440	Self carbon changing	Each	THAILAND	350	0
441	Self Overhauling	Each	THAILAND	1200	0
442	Self rewinding	Each	THAILAND	900	0
443	Shock absorber changing	Each	THAILAND	200	0
444	Side door glass changing	Each	THAILAND	350	0
445	Solonoid switch changing	Each	THAILAND	450	0
446	Spring buffer mounting	Each	THAILAND	200	0
	changing				
447	Spring bush changing	Each	THAILAND	150	0
448	spring clam welding	per piece	THAILAND	10	0
449	Spring clam changing	Each	THAILAND	200	0
450	Spring hanger changing	Each	THAILAND	300	0
451	Spring pin bush changing	Each	THAILAND	20	0
452	Spring Shackle pin	Each	THAILAND	20	0
	changing				
453	Steering box kit changing	Each	THAILAND	250	0
454	Steering box oil seal	Each	THAILAND	690	0
	changing				
455	Steering box overhauling	Each	THAILAND	1200	0
456	Steering Column changing	Each	THAILAND	200	0
	(inner)				
457	Steering Column changing	Each	THAILAND	350	0
	(Outer)				
458	Steering cross bearing	Each	THAILAND	450	0
	changing				
459	Steering cross changing	Each	THAILAND	550	0
460	Steering rack changing	Each	THAILAND	750	0
461	Steering wheel opening &	Each	THAILAND	100	0
	refitting				
462	Tail pinion oil seal change	Each	THAILAND	350	0
463	Tailgate Repairing	Each	THAILAND	200	0
464	Tappet adjusting	Each	THAILAND	100	0
465	Tie rod end changing	Each	THAILAND	550	0
466	Tie rod kit changing	Each	THAILAND	550	0
467	Timing belt changing	Each	THAILAND	950	0
468	Timing cover gear	Each	THAILAND	950	0
	changing				
469	Transmission half	Each	THAILAND	1200	0
	overhauling				
470	Transmission over hauling	Each	THAILAND	1200	0
471	U bolt changing	Each	THAILAND	200	0

472	Upper clutch kit changing	Each	THAILAND	200	0
473	Upper Radiator hose pipe changing	Each	THAILAND	350	0
474	Vaccum pipe changing	Each	THAILAND	350	0
475	vacuum nozzle pipe changing	each	THAILAND	450	0
476	Vacuum pipe socket changing	Each	THAILAND	350	0
477	Valve O ring changing	Each	THAILAND	450	0
478	Valve oil seal changing	Each	THAILAND	350	0
479	Valve spring changing	Each	THAILAND	200	0
480	Water filter changing	Each	THAILAND	350	0
481	Water level indicator pipe changing	Each	THAILAND	250	0
482	Water pump assy servicing	Each	THAILAND	450	0
483	Water separator changing	Each	THAILAND	250	0
484	Water separator servicing	Each	THAILAND	250	0
485	Wind shield replacing	Each	THAILAND	200	0
486	Wiper arm changing	Each	THAILAND	1200	0
487	Wiper blade changing	Each	THAILAND	20	0
488	Wiper motor changing	Each	THAILAND	50	0
489	Wiper motor repairing	Each	THAILAND	1200	0